MICROWAVE POPCORN BUCKET

Instruction Manual

SAVE THIS INSTRUCTION MANUAL FOR FUTURE REFERENCE

To prevent injury or property damage, read all instructions and warnings before use.

Do not touch hot surfaces. Use oven mitt or hot pad. Close supervision is necessary when this popper appliance is used. Never leave microwave oven unattended during popping. Do not place on or near a hot gas or electric burner, or in a heated oven. Do not use appliance for other than intended use. Do not scratch the surface of the bucket.

HOW TO USE

- 1. Wash the bucket in warm, soapy water. Rinse and dry thoroughly. .
- 2. Place ¼ cup of popcorn kernels into the bucket.
- 3. Oil is not necessary to pop popcorn. If desired, add a tea spoon vegetable oil to bowl prior to popping.
- Cover bucket with lid and microwave on high power for 2 to 4 minutes. Times may vary by microwave.
 Listen carefully, popcorn is done when there is a pause of few seconds between pops. If more or less time is necessary, adjust timer accordingly for your next batch of popcorn. Do not overcook as popcorn will scorch.
- 5. The popped corn may push the lid up while popping, this is normal.
- Bucket is HOT, remove from microwave with mitts or hot pads carefully.
 Caution: Some hot oil residue may remain in the bottom of the bucket after popping.
- 7. Add seasonings, melted butter or margarine to popcorn if desired