

Instructions for attaching Gummi Crib Rail Cover to a curved crib rail.

1. Follow **ALL** of the standard directions on front of instruction sheet (page 1) and see diagrams 1 and 2 below to attach the Gummi Crib Rail over a curved edge.
2. Place the Gummi Crib Rail flat on top of the curved rail. When sides are folded down to allow attachment of adhesive, you will notice small pucker areas along the curve. These are the locations for making the small notches. Using scissors, cut a very small "v" shaped notch. This may need to be done two or three times on each side, depending on our cribs curvature. **Caution: Cut the notch just slightly deeper than the tape edge, approximately 1/2". ONLY.**
3. Position Gummi Crib Rail flat on top of curved rail. Pull backing from small section of Gummi Rail adhesive and secure to crib. Remove backing from next section of Gummi and pull sides of "v" notch as closely together as possible pressing adhesive onto crib. Follow this procedure until Gummi Rail is completely attached. Allow 8 to 10 hours for adhesive to bond, before placing child in crib.

