


Step into a Great Fit!

14956 Stay-Put Adjustable Swim Shoes Size Chart

IMPORTANT! Print out the size chart at **100%**. Make sure Page Scaling is set to "No scaling" and printing options are **NOT** set "Fit to page." To check accuracy, measure the chart with a ruler; it should be 9" from end to end.



SIZE 3	Max. Foot Length: 8 1/2"L	SIZE 3
SIZE 2	Max. Foot Length: 8 1/8"L	SIZE 2
SIZE 1	Max. Foot Length: 7 3/4"L	SIZE 1
SIZE 13	Max. Foot Length: 7 1/2"L	SIZE 13
SIZE 12	Max. Foot Length: 7 1/8"L	SIZE 12
SIZE 11	Max. Foot Length: 6 3/4"L	SIZE 11
SIZE 10	Max. Foot Length: 6 1/2"L	SIZE 10
SIZE 9	Max. Foot Length: 6 1/8 "L	SIZE 9
SIZE 8	Max. Foot Length: 5 7/8 "L	SIZE 8
SIZE 7	Max. Foot Length: 5 1/2"L	SIZE 7
SIZE 6	Max. Foot Length: 5 1/4"L	SIZE 6
SIZE 5	Max. Foot Length: 4 7/8"L	SIZE 5
	Place Heel Her	e



How this shoe fits: Adjustable strap allows child to choose best fit.

4 Quick Steps To a Great Fit!

- Kids' feet are always
 "on the grow," so measure before you order.
- 2 Everyone has 1 larger foot, so measure both feet. This shoe's fit runs bigger than others in our collection. Please base the size on your child's smaller foot.
- If your child's larger foot is in between two sizes, order the smaller size.

Kids should stand with weight distributed evenly on both feet. If your child will wear socks with the shoes, he/she should wear socks while measuring (and vice versa).

To order or ask questions: call **1-800-274-8440** or email **questions@onestepahead.com** We're here to help!